


# SPRUE PUNCH / BRASS ROD

### ■ Application Remove resin clogged in the sprue bushing.



#### ■ Set Product (Body + Spare Pin Punch × 5 pcs)

Pin punch dia. ( $\phi$ )	L	Part Number	Unit Price 1~2 pcs
2.8	425	M-SPNS	Quetation
4.0	730	M-SPNS-L	Quotation

Order Part number

M—SPNS

M—SPNS—S


For quantities not displayed here, refer to our MISUMI website for more information.
 Spare Pin Punch (Single unit)

	( - 5	-7		
Pin punch dia.	Quantity	Part Number	Unit Price	
$(\phi)$	(pcs)	Part Number	1~2 pcs	
2.8	- 5	M-SPNS-S	Quetation	
4 0		M-SDNS-I-S	Quotation	

Days to Ship Quotation







#### ■ How to Use

- ullet Place the sprue punch to the nozzle touch side of the sprue bushing and move the heating cylinder forward.
- The pin punch stored by the spring will be pushed by the nozzle and protrude, removing the affixed sprue.

## Application Remove resin clogged in the sprue bushing easily.



## ■ Set Product (Body + Tip × 4 pcs)

Tip end	Tip dia. ( $\phi$ )	Tip shape	Total length (with tip mounted)		Unit Price 1~3 pcs	
φ4	0	Round	540	M-BR	Quotation	
5	0	Chisel	M-BR-3	Quotation		
■ Spare Tip	p (Single unit) To requantities not displayed here, refer to our MISUMI website for more information					
Tin end	Tip dia (4)	Tip	Quantity (ncs)	Part Number	Unit Price	



Days to Ship









For quantities not displayed here, refer to our MISUMI website for more information.