

DANH SÁCH SẢN PHẨM SẴP NGỪNG CUNG CẤP
 LIST OF ITEMS TO BE DISCONTINUED (*Be discontinued after clearing stock)

Cập nhật / Update:09-Aug-2019

STT No	Mã hàng Part Number	Tên hàng Product Name	Thương hiệu Brand	Tình trạng / Status Discontinued or Available
1	PCPU-FSB-B75G-R	LGAI155 FULL CPU CARD	MISUMI	Available
2	PCBC-AEC204-SI	JOY CHASSIS	MISUMI	Available
3	ACC-JAC6L23C	CPU FAN	MISUMI	Available
4	PCBC-AEC206	JOY CHASSIS	MISUMI	Available
5	PCBP-206SIV60-R	RPC BACKPLANE	MISUMI	Available
6	PCBP-206SGP4-R	RPC BACKPLANE	MISUMI	Available
7	PCBC-AEC206-SGP4	JOY CHASSIS	MISUMI	Available
8	PCBC-AEC204-SPP3	JOY CHASSIS	MISUMI	Discontinued
9	PCBP-214SGP12-R	RPC BACKPLANE	MISUMI	Available
10	PCBC-AEC204	JOY CHASSIS	MISUMI	Available
11	PCBP-204SPP3N-R	RPC BACKPLANE	MISUMI	Discontinued
12	PCBP-204SI-R	RPC BACKPLANE	MISUMI	Available
13	PCMB-EMB845M	S478 MOTHERBOARD	MISUMI	Discontinued
14	EMB-845M-A10.	S478 MOTHERBOARD	MISUMI	Discontinued
15	AP-FN1759218-000.	CPU FAN	MISUMI	Available
16	ACC-JAC6L23C-R	* CPU FAN	MISUMI	Discontinued
17	PCPU-SBC780-E2	CPU CARD	MISUMI	Discontinued
18	SBC-780-A10.	CPU CARD	MISUMI	Discontinued
19	PCPU-SBC780-VE	CPU CARD	MISUMI	Discontinued
20	SBC-780-A10-01.	CPU CARD	MISUMI	Discontinued
21	PCPU-SBC780-VER	CPU CARD	MISUMI	Discontinued
22	TF-SBC-780-A11-01.	CPU CARD	MISUMI	Discontinued
23	PCPU-SBC659-B11	CPU CARD	MISUMI	Discontinued
24	SBC-659-B11.	CPU CARD	MISUMI	Discontinued
25	PCPU-HSB660I	CPU CARD	MISUMI	Discontinued
26	HSB-660I-A10-01.	CPU CARD	MISUMI	Discontinued
27	PCPU-SBC659P-A11	CPU CARD	MISUMI	Discontinued
28	SBC-659P-A11.	CPU CARD	MISUMI	Discontinued
29	PCPU-FSB865G-G2	CPU CARD	MISUMI	Discontinued
30	FSB-865G-A10-G2.	CPU CARD	MISUMI	Discontinued
31	PCPU-FSB865G-VG	CPU CARD	MISUMI	Discontinued
32	FSB-865G-A10-VG.	CPU CARD	MISUMI	Discontinued
33	PCPU-FSB860B-E2	CPU CARD	MISUMI	Discontinued
34	FSB-860B-A10E2.	CPU CARD	MISUMI	Discontinued
35	FSB-860B-A10VE.	CPU CARD	MISUMI	Discontinued
36	PCPU-FSB865G-G2R	CPU CARD	MISUMI	Discontinued
37	TF-FSB-865G-A11-G2.	CPU CARD	MISUMI	Discontinued
38	PCPU-FSB865G-VGR	CPU CARD	MISUMI	Discontinued
39	TF-FSB-865G-A11-VG.	CPU CARD	MISUMI	Discontinued
40	PCPU-FSB860B-VE-R	CPU CARD	MISUMI	Discontinued
41	TF-FSB-860B-A10VE.	CPU CARD	MISUMI	Discontinued
42	PCPU-FSB865G-E2-R	CPU CARD	MISUMI	Discontinued
43	TF-FSB-865G-B10-E2.	CPU CARD	MISUMI	Discontinued
44	TF-FSB-865G-B10-G2.	CPU CARD	MISUMI	Discontinued
45	PCPU-HSB657I-E667	CPU CARD	MISUMI	Discontinued
46	R-HSB657I-0001	CPU CARD	MISUMI	Discontinued
47	PCPU-HSB668I-R	CPU CARD	MISUMI	Discontinued
48	R-TFHSB-668I-0004	CPU CARD	MISUMI	Discontinued
49	R-TFHSB-668I-0003	CPU CARD	MISUMI	Discontinued
50	PCPU-HSB525I-R	CPU CARD	MISUMI	Discontinued
51	HSB-525I-A10-M001.	CPU CARD	MISUMI	Discontinued
52	PCPU-SBC657-E667	CPU CARD	MISUMI	Discontinued
53	SBC-657-B10-02.	CPU CARD	MISUMI	Discontinued
54	FSB-B75G-A10-M001.	LGAI155 FULL CPU CARD	MISUMI	Discontinued
55	17001-00051	IPC CHASSIS	MISUMI	Available
56	R-AEC206G2-0000	JOY CHASSIS	MISUMI	Discontinued
57	AEC-206-H20-B-C00	JOY CHASSIS	MISUMI	Discontinued
58	TF-AEC-206-H20-B-C01.	JOY CHASSIS	MISUMI	Available
59	PCBC-AEC206-SIV60	JOY CHASSIS	MISUMI	Available
60	PCBC-AEC206-WOPS	JOY CHASSIS	MISUMI	Available
61	AEC-204P1-01	JOY CHASSIS	MISUMI	Discontinued
62	AEC-204-H15-W-C00	JOY CHASSIS	MISUMI	Available
63	PCBC-AEC204-SSP2	JOY CHASSIS	MISUMI	Discontinued
64	BP-214SG-P12-A11	RPC BACKPLANE	MISUMI	Discontinued
65	BP-214SG-P7-A11	RPC BACKPLANE	MISUMI	Discontinued
66	BP-214SG-P4-A11	RPC BACKPLANE	MISUMI	Discontinued
67	TF-BP-214SG-P12-A11.	RPC BACKPLANE	MISUMI	Available
68	PCBP-214SGP7-R	RPC BACKPLANE	MISUMI	Available
69	TF-BP-214SG-P7-A11.	RPC BACKPLANE	MISUMI	Available
70	PCBP-214SGP4-R	RPC BACKPLANE	MISUMI	Available
71	BP-206SG-P4-A11	RPC BACKPLANE	MISUMI	Discontinued
72	BP-206SI-V60	RPC BACKPLANE	MISUMI	Discontinued
73	TF-BP-206SG-P4-A11	RPC BACKPLANE	MISUMI	Available
74	PCBP-204SSP2	RPC BACKPLANE	MISUMI	Discontinued
75	BP-204SS-P2-A10	RPC BACKPLANE	MISUMI	Discontinued

DANH SÁCH SẢN PHẨM SẴP NGỪNG CUNG CẤP
 LIST OF ITEMS TO BE DISCONTINUED (*Be discontinued after clearing stock)

Cập nhật / Update:09-Aug-2019

STT No	Mã hàng Part Number	Tên hàng Product Name	Thương hiệu Brand	Tình trạng / Status Discontinued or Available
76	BP-204SI-A13	RPC BACKPLANE	MISUMI	Discontinued
77	BP-204SP-P3-A11	RPC BACKPLANE	MISUMI	Discontinued
78	TF-BP-204SI-A13	RPC BACKPLANE	MISUMI	Available
79	PCBP-208SGP7-R	RPC BACKPLANE	MISUMI	Discontinued
80	TF-BP-208SG-P7-A11.	RPC BACKPLANE	MISUMI	Discontinued
81	PCBP-208SGP4-R	RPC BACKPLANE	MISUMI	Discontinued
82	TF-BP-208SG-P4-A11.	RPC BACKPLANE	MISUMI	Discontinued
83	PC4-PCM3724N-R	DIO MODULE	MISUMI	Discontinued
84	R-TFPCM3724-000	DIO MODULE	MISUMI	Discontinued
85	PC4-GENE-8310	PC BOARD	MISUMI	Discontinued
86	GENE-8310-A10.	PC BOARD	MISUMI	Discontinued
87	PC4-GENE-8310-R	PC BOARD	MISUMI	Discontinued
88	TF-GENE-8310-A11.	PC BOARD	MISUMI	Discontinued
89	PC4-GENE-6350	PC BOARD	MISUMI	Discontinued
90	GENE-6350-A10.	PC BOARD	MISUMI	Discontinued
91	PC4-GENE-6350R	PC BOARD	MISUMI	Discontinued
92	TF-GENE-6350-A20.	PC BOARD	MISUMI	Discontinued
93	PC4-PFM620S-650	PC BOARD	MISUMI	Discontinued
94	PFM-620SA10-01.	PC BOARD	MISUMI	Discontinued
95	PC4-PFM620S-400	PC BOARD	MISUMI	Discontinued
96	PFM-620SA10.	PC BOARD	MISUMI	Discontinued
97	PC4-PFM620S-400-R	PC BOARD	MISUMI	Discontinued
98	TF-PFM-620S-A11.	PC BOARD	MISUMI	Discontinued
99	PC4-PFM620S-650-R	PC BOARD	MISUMI	Discontinued
100	TF-PFM-620S-A11-01.	PC BOARD	MISUMI	Discontinued
101	PC4-GENE-4312	PC BOARD	MISUMI	Discontinued
102	GENE-4312-A11.	PC BOARD	MISUMI	Discontinued
103	TF-AOP-8150HT-A1-512MB	PANEL IPC	MISUMI	Discontinued
104	AEC206-H20-B-C00-PC	IPC CHASSIS	MISUMI	Discontinued
105	TF-BP-206SI-A11	RPC BACKPLANE	MISUMI	Available
106	TF-BP-204SP-P3-A11	RPC BACKPLANE	MISUMI	Discontinued
107	TF-BP-214SG-P4-A11-01.	RPC BACKPLANE	MISUMI	Available
108	1759218000-PC	CPU FAN	MISUMI	Available
109	PCPU-FSB865G-B10-R	CPU CARD	MISUMI	Discontinued
110	TF-AOP-8120HT-A1-512MB	PANEL IPC	MISUMI	Discontinued
111	PCPU-FSB860B-VE	CPU CARD	MISUMI	Discontinued
112	PCBP-214SGP12	RPC BACKPLANE	MISUMI	Discontinued
113	PCBP-214SGP7	RPC BACKPLANE	MISUMI	Discontinued
114	PCBP-214SGP4	RPC BACKPLANE	MISUMI	Discontinued
115	PCBP-206SGP4	RPC BACKPLANE	MISUMI	Discontinued
116	PCBP-206SIV60	RPC BACKPLANE	MISUMI	Discontinued
117	PCBP-204SI	RPC BACKPLANE	MISUMI	Discontinued
118	PCBP-204SPP3	RPC BACKPLANE	MISUMI	Discontinued
119	FSB-B75G-A10-M002.	LGAI1155 FULL CPU CARD	MISUMI	Available
120	DPAM-C2-VC10S	DISPLAY MOUNT	MISUMI	Available
121	DPAM-C2-VC11S	DISPLAY MOUNT	MISUMI	Available
122	DPAM-C2-HC11S	DISPLAY MOUNT	MISUMI	Discontinued
123	DPAM-C2-HC10S	DISPLAY MOUNT	MISUMI	Discontinued
124	DPAM-C2-VW11S	DISPLAY MOUNT	MISUMI	Discontinued
125	GMC-20P2-AC100V	SINGLE PHASE CONTACTOR	MISUMI	Available
126	MCR-6A-DC24V	ELECTROMAGNETIC CONTACTER	MISUMI	Available
127	MCR-65A-AC200V	ELECTROMAGNETIC SWITCH	MISUMI	Available
128	MCR-22B-DC24V	ELECTROMAGNETIC SWITCH	MISUMI	Available
129	MCR-32A-AC200V	ELECTROMAGNETIC SWITCH	MISUMI	Available
130	AS-12M-4	MINI CONTACTOR	MISUMI	Available
131	US-3	ELECTROMAGNETIC SWITCH	MISUMI	Available
132	GMC-20P2-AC200V	SINGLE PHASE CONTACTOR	MISUMI	Available
133	MCR-9B-DC24V	ELECTROMAGNETIC SWITCH	MISUMI	Available
134	GMC-10P2-AC100V	SINGLE PHASE CONTACTOR	MISUMI	Available
135	MCR-22B-AC200V	ELECTROMAGNETIC SWITCH	MISUMI	Available
136	MCR-50A-AC200V	ELECTROMAGNETIC SWITCH	MISUMI	Available
137	MCR-18B-AC200V	ELECTROMAGNETIC SWITCH	MISUMI	Available
138	MCR-6A-AC200V	ELECTROMAGNETIC SWITCH	MISUMI	Available
139	GMC-40P2-AC100V	SINGLE PHASE CONTACTOR	MISUMI	Available
140	GMC-30P2-AC100V	SINGLE PHASE CONTACTOR	MISUMI	Available
141	KHK9-AC200V-15	ELECTROMAGNETIC SWITCH	MISUMI	Available
142	KHK6-DC24V-2.1	ELECTROMAGNETIC SWITCH	MISUMI	Available
143	GMC-40P2-AC200V	SINGLE PHASE CONTACTOR	MISUMI	Available
144	MCR-50A-AC100V	ELECTROMAGNETIC SWITCH	MISUMI	Available
145	US-4	SURGE ABSORBER	MISUMI	Available
146	TBS-23	BREAKER	MISUMI	Available
147	MCR-32A-AC100V	ELECTROMAGNETIC SWITCH	MISUMI	Available
148	TBS-22	BREAKER	MISUMI	Available
149	KHK6-DC24V-0.52	ELECTROMAGNETIC SWITCH	MISUMI	Available
150	MCR-6A-AC100V	ELECTROMAGNETIC SWITCH	MISUMI	Available

DANH SÁCH SẢN PHẨM SẴP NGỪNG CUNG CẤP
 LIST OF ITEMS TO BE DISCONTINUED (*Be discontinued after clearing stock)

Cập nhật / Update:09-Aug-2019

STT No	Mã hàng Part Number	Tên hàng Product Name	Thương hiệu Brand	Tình trạng / Status Discontinued or Available
151	KHK18-DC24V-15	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
152	KHK6-DC24V-3.3	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
153	GMC-25P2-AC100V	SINGLE PHASE CONTACTOR	MISUMI	Avai lable
154	US-11	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
155	KHK6-AC200V-2.1	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
156	US-2	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
157	GMC-10P2-AC200V	SINGLE PHASE CONTACTOR	MISUMI	Avai lable
158	KHK6-DC24V-1.3	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
159	MCR-9B-AC100V	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
160	KHK12R-DC24V-2.1	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
161	GMC-30P2-AC200V	SINGLE PHASE CONTACTOR	MISUMI	Avai lable
162	KHK12-AC200V-8.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
163	KHK6R-DC24V-0.52	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
164	KHK6-DC24V-5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
165	MCR-12B-DC24V	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
166	KHK6-DC24V-0.82	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
167	MCR-18B-DC24V	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
168	GTH-12M-2.1	MINI CONTACTOR	MISUMI	Avai lable
169	KHK6-AC200V-3.3	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
170	MCR-22B-AC100V	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
171	KHK9-DC24V-2.1	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
172	MCR-12B-AC200V	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
173	UA-1	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
174	KHK9R-DC24V-2.1	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
175	KHK9R-DC24V-7.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
176	KHK6R-DC24V-3.3	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
177	MCR-9B-AC200V	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
178	GMC-12M-AC100V	MINI CONTACTOR	MISUMI	Avai lable
179	KHK6R-AC200V-1.3	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
180	KHK9R-AC200V-2.1	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
181	EBS-53C-50A	LEAKAGE BREAKER	MISUMI	Avai lable
182	EBS-103FB-60A-100MA	LEAKAGE BREAKER	MISUMI	Avai lable
183	KHK6R-AC200V-0.82	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
184	KHK9-DC24V-3.3	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
185	MCR-18B-AC100V	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
186	KHK12-DC24V-2.1	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
187	UA-2-2A	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
188	MCR-12B-AC100V	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
189	KHK6R-DC24V-0.82	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
190	KHK6-DC24V-8.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
191	KHK32-AC200V-27	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
192	KHK9-DC24V-1.3	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
193	KHK6-AC100V-2.1	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
194	UR-02	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
195	KHK6-AC200V-8.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
196	KHK6-AC200V-7.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
197	KHK6-AC200V-1.3	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
198	KHK9-DC24V-15	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
199	KHK9-AC200V-2.1	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
200	GMC-35P2-AC100V	SINGLE PHASE CONTACTOR	MISUMI	Avai lable
201	KHK9-AC200V-3.3	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
202	AZ-12MH	MINI CONTACTOR	MISUMI	Avai lable
203	KHK50-AC200V-55S	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
204	AX-23R-W	BREAKER	MISUMI	Avai lable
205	KHK6-AC100V-0.82	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
206	GMC-35P2-AC200V	SINGLE PHASE CONTACTOR	MISUMI	Avai lable
207	KHK9-DC24V-6.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
208	EH100S	BREAKER	MISUMI	Avai lable
209	KHK22-DC24V-21.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
210	GMC-16M-AC100V	MINI CONTACTOR	MISUMI	Avai lable
211	KHK22-AC200V-27	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
212	KHK9R-DC24V-0.82	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
213	AS-12M-3	MINI CONTACTOR	MISUMI	Avai lable
214	KHK22R-AC200V-15	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
215	GTH-12M-0.82	MINI CONTACTOR	MISUMI	Avai lable
216	KHK6-AC100V-3.3	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
217	KHK6-AC200V-0.82	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
218	KHK9-AC100V-11	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
219	KHK9-AC100V-15	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
220	KHK12-AC200V-15	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
221	US-13	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
222	KHK6-DC24V-6.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
223	KHK6R-DC24V-1.3	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
224	KHK6-AC100V-1.3	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
225	KHK9R-AC200V-0.82	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable

DANH SÁCH SẢN PHẨM SẴP NGỪNG CUNG CẤP
 LIST OF ITEMS TO BE DISCONTINUED (*Be discontinued after clearing stock)

Cập nhật / Update:09-Aug-2019

STT No	Mã hàng Part Number	Tên hàng Product Name	Thương hiệu Brand	Tình trạng / Status Discontinued or Available
226	KHK9R-AC200V-3.3	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
227	KHK9R-AC100V-3.3	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
228	KHK12R-DC24V-3.3	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
229	KHK6-AC200V-0.52	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
230	KHK18-AC200V-15	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
231	KHK9-AC200V-8.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
232	MCR-65A-AC100V	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
233	GTH-12M-7.5	MINI CONTACTOR	MISUMI	Avai lable
234	KHK9-AC200V-1.3	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
235	KHK9-DC24V-0.82	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
236	KHK6-AC200V-5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
237	KHK6R-AC200V-3.3	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
238	KHK6R-AC100V-1.3	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
239	US-12	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
240	KHK12-AC200V-2.1	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
241	KHK6-AC200V-6.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
242	KHK12-DC24V-11	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
243	KHK32R-AC200V-2.1	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
244	KHK9R-AC200V-6.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
245	KHK9R-AC100V-11	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
246	SMR-32-21.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
247	KHK6-AC100V-8.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
248	KHK12-AC200V-11	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
249	KHK9-AC200V-0.52	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
250	KHK22-AC200V-15	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
251	KHK9-DC24V-7.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
252	KHK9-DC24V-8.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
253	KHK9-DC24V-11	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
254	SMR-12-2.1	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
255	UW-32	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
256	KHK22R-AC100V-2.1	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
257	KHK9-AC100V-3.3	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
258	KHK18-DC24V-8.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
259	KHK6R-AC200V-0.52	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
260	KHK6R-AC100V-0.82	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
261	KHK6-DC24V-7.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
262	KHK22R-DC24V-15	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
263	KHK12-DC24V-5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
264	KHK12-DC24V-8.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
265	KHK18R-AC200V-19	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
266	KHK18R-AC200V-27	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
267	KHK18R-AC100V-19	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
268	UA-2-1A1B	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
269	KHK6-AC100V-5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
270	KHK6-AC100V-0.52	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
271	KHK50R-AC200V-55S	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
272	KHK9-AC200V-6.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
273	AL-23R-W	BREAKER	MISUMI	Avai lable
274	GMC-25P2-AC200V	SINGLE PHASE CONTACTOR	MISUMI	Avai lable
275	KHK12-AC100V-7.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
276	KHK22-DC24V-8.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
277	KHK12R-AC200V-7.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
278	KHK12R-AC200V-8.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
279	KHK12R-AC200V-15	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
280	AS-12M-2	MINI CONTACTOR	MISUMI	Avai lable
281	SMR-12-3.3	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
282	KHK9-DC24V-0.52	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
283	GTH-12M-14	MINI CONTACTOR	MISUMI	Avai lable
284	KHK9R-AC100V-7.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
285	KHK12R-DC24V-1.3	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
286	KHK12R-DC24V-15	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
287	KHK50-AC200V-30S	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
288	KHK50-AC200V-34S	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
289	SMR-32-1.3	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
290	KHK9-AC200V-11	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
291	KHK22-AC200V-21.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
292	KHK32-AC100V-2.1	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
293	UA-4-2A2B	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
294	DH100S	BREAKER	MISUMI	Avai lable
295	AX-R-W	BREAKER	MISUMI	Avai lable
296	KHK9R-DC24V-0.52	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
297	KHK9R-DC24V-1.3	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
298	KHK18-AC100V-15	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
299	KHK18-AC100V-27	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
300	KHK18-DC24V-3.3	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable

DANH SÁCH SẢN PHẨM SẴP NGỪNG CUNG CẤP
LIST OF ITEMS TO BE DISCONTINUED (*Be discontinued after clearing stock)

Cập nhật / Update:09-Aug-2019

STT No	Mã hàng Part Number	Tên hàng Product Name	Thương hiệu Brand	Tình trạng / Status Discontinued or Available
301	KHK18-DC24V-5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
302	SMR-32-8.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
303	SMR-32-3.3	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
304	GMC-9M-AC100V	MINI CONTACTOR	MISUMI	Avai lable
305	KHK32R-AC200V-8.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
306	KHK32R-AC200V-11	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
307	KHK32R-AC200V-15	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
308	KHK32R-AC200V-19	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
309	KHK32R-AC100V-6.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
310	KHK32R-AC100V-8.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
311	KHK32R-AC200V-27	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
312	SMR-32-0.82	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
313	KHK12-AC100V-8.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
314	KHK22-AC200V-6.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
315	KHK22-AC100V-2.1	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
316	SMR-12-0.82	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
317	KHK65-AC200V-55S	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
318	SMR-12-1.3	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
319	KHK6R-DC24V-2.1	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
320	KHK6R-DC24V-7.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
321	KHK6R-DC24V-8.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
322	SMR-32-7.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
323	KHK6-AC100V-6.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
324	TCL-13	BREAKER	MISUMI	Avai lable
325	UA-4-4A	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
326	KHK18-AC200V-3.3	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
327	KHK9-AC100V-6.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
328	GTH-12M-12	MINI CONTACTOR	MISUMI	Avai lable
329	KHK18R-AC200V-6.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
330	KHK18R-AC100V-3.3	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
331	SMR-32-2.1	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
332	SMR-32-6.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
333	SMR-32-11	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
334	SMR-32-15	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
335	SMR-32-27	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
336	AL-23R-B	BREAKER	MISUMI	Avai lable
337	KHK12-AC200V-27	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
338	KHK12-AC100V-3.3	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
339	KHK22-DC24V-19	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
340	KHK22-DC24V-27	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
341	KHK12R-AC200V-11	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
342	KHK12R-AC200V-21.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
343	KHK12R-AC100V-1.3	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
344	KHK12R-AC100V-8.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
345	KHK12R-AC100V-15	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
346	TCS-13	BREAKER	MISUMI	Avai lable
347	KHK9R-AC200V-0.52	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
348	KHK9R-AC200V-11	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
349	KHK9R-AC100V-0.82	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
350	KHK9R-AC100V-6.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
351	SMR-12-6.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
352	SMR-12-8.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
353	KHK9-AC200V-0.82	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
354	KHK22-AC200V-0.82	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
355	KHK9-AC100V-0.82	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
356	KHK9-AC100V-2.1	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
357	KHK9-AC100V-7.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
358	KHK9-AC100V-8.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
359	KHK22-AC100V-15	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
360	KHK22-AC100V-27	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
361	TBS-13B	BREAKER	MISUMI	Avai lable
362	KHK22-AC200V-2.1	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
363	KHK22-AC100V-21.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
364	AX-23R-B	BREAKER	MISUMI	Avai lable
365	KHK18-AC200V-8.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
366	KHK18-DC24V-2.1	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
367	KHK18-DC24V-7.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
368	KHK18-DC24V-21.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
369	KHK6R-AC200V-2.1	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
370	KHK6R-AC200V-5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
371	KHK6R-AC200V-8.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
372	KHK6R-AC100V-3.3	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
373	SMR-12-5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
374	KHK12-DC24V-1.3	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
375	KHK12-DC24V-3.3	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable

DANH SÁCH SẢN PHẨM SẴP NGỪNG CUNG CẤP
 LIST OF ITEMS TO BE DISCONTINUED (*Be discontinued after clearing stock)

Cập nhật / Update:09-Aug-2019

STT No	Mã hàng Part Number	Tên hàng Product Name	Thương hiệu Brand	Tình trạng / Status Discontinued or Available
376	KHK12-DC24V-15	ELECTROMAGNETIC SWITCH	MISUMI	Available
377	KHK12-DC24V-21.5	ELECTROMAGNETIC SWITCH	MISUMI	Available
378	KHK6-AC100V-7.5	ELECTROMAGNETIC SWITCH	MISUMI	Available
379	KHK12-AC200V-1.3	ELECTROMAGNETIC SWITCH	MISUMI	Available
380	KHK12-AC200V-6.5	ELECTROMAGNETIC SWITCH	MISUMI	Available
381	KHK12-AC100V-1.3	ELECTROMAGNETIC SWITCH	MISUMI	Available
382	KHK12-AC100V-11	ELECTROMAGNETIC SWITCH	MISUMI	Available
383	KHK9-DC24V-5	ELECTROMAGNETIC SWITCH	MISUMI	Available
384	KHK9-DC24V-21.5	ELECTROMAGNETIC SWITCH	MISUMI	Available
385	KHK9-AC200V-5	ELECTROMAGNETIC SWITCH	MISUMI	Available
386	KHK9-AC200V-27	ELECTROMAGNETIC SWITCH	MISUMI	Available
387	KHK32-AC200V-3.3	ELECTROMAGNETIC SWITCH	MISUMI	Available
388	KHK32-AC200V-15	ELECTROMAGNETIC SWITCH	MISUMI	Available
389	KHK32-AC100V-15	ELECTROMAGNETIC SWITCH	MISUMI	Available
390	KHK32-AC100V-21.5	ELECTROMAGNETIC SWITCH	MISUMI	Available
391	SMR-32-0.52	ELECTROMAGNETIC SWITCH	MISUMI	Available
392	SMR-32-5	ELECTROMAGNETIC SWITCH	MISUMI	Available
393	SMR-32-19	ELECTROMAGNETIC SWITCH	MISUMI	Available
394	TCS-12	BREAKER	MISUMI	Available
395	TCL-12	BREAKER	MISUMI	Available
396	KHK22-AC200V-3.3	ELECTROMAGNETIC SWITCH	MISUMI	Available
397	KHK22-AC200V-19	ELECTROMAGNETIC SWITCH	MISUMI	Available
398	AL-T-W	BREAKER	MISUMI	Available
399	KHK18-AC200V-2.1	ELECTROMAGNETIC SWITCH	MISUMI	Available
400	KHK18-AC200V-11	ELECTROMAGNETIC SWITCH	MISUMI	Available
401	KHK18-AC200V-21.5	ELECTROMAGNETIC SWITCH	MISUMI	Available
402	KHK18-AC100V-7.5	ELECTROMAGNETIC SWITCH	MISUMI	Available
403	SMR-12-7.5	ELECTROMAGNETIC SWITCH	MISUMI	Available
404	UW-22	ELECTROMAGNETIC SWITCH	MISUMI	Available
405	KHK12-AC200V-3.3	ELECTROMAGNETIC SWITCH	MISUMI	Available
406	KHK12-AC200V-7.5	ELECTROMAGNETIC SWITCH	MISUMI	Available
407	KHK12-AC200V-21.5	ELECTROMAGNETIC SWITCH	MISUMI	Available
408	KHK12-AC100V-5	ELECTROMAGNETIC SWITCH	MISUMI	Available
409	KHK12-AC100V-6.5	ELECTROMAGNETIC SWITCH	MISUMI	Available
410	KHK12-AC100V-15	ELECTROMAGNETIC SWITCH	MISUMI	Available
411	KHK9-AC100V-5	ELECTROMAGNETIC SWITCH	MISUMI	Available
412	AL-R-W	BREAKER	MISUMI	Available
413	SMR-12-0.52	ELECTROMAGNETIC SWITCH	MISUMI	Available
414	SMR-63-55S	ELECTROMAGNETIC SWITCH	MISUMI	Available
415	UW-18	ELECTROMAGNETIC SWITCH	MISUMI	Available
416	ABE-52B-5A	BREAKER	MISUMI	Discontinued
417	ABE-52B-10A	BREAKER	MISUMI	Discontinued
418	ABE-52B-15A	BREAKER	MISUMI	Discontinued
419	ABE-52B-20A	BREAKER	MISUMI	Discontinued
420	ABE-52B-30A	BREAKER	MISUMI	Discontinued
421	ABE-52B-40A	BREAKER	MISUMI	Discontinued
422	ABE-52B-50A	BREAKER	MISUMI	Discontinued
423	ABE-62B-60A	BREAKER	MISUMI	Discontinued
424	ABE-102B-75A	BREAKER	MISUMI	Discontinued
425	ABE-102B-100A	BREAKER	MISUMI	Discontinued
426	ABE-53B-5A	BREAKER	MISUMI	Discontinued
427	ABE-53B-10A	BREAKER	MISUMI	Discontinued
428	ABE-53B-20A	BREAKER	MISUMI	Discontinued
429	ABE-53B-30A	BREAKER	MISUMI	Discontinued
430	ABE-53B-40A	BREAKER	MISUMI	Discontinued
431	ABE-53B-50A	BREAKER	MISUMI	Discontinued
432	ABE-63B-60A	BREAKER	MISUMI	Discontinued
433	ABE-103B-75A	BREAKER	MISUMI	Discontinued
434	ABE-103B-100A	BREAKER	MISUMI	Discontinued
435	ABS-32B-3A	BREAKER	MISUMI	Discontinued
436	ABS-32B-5A	BREAKER	MISUMI	Discontinued
437	ABS-32B-10A	BREAKER	MISUMI	Discontinued
438	ABS-32B-15A	BREAKER	MISUMI	Discontinued
439	ABS-32B-20A	BREAKER	MISUMI	Discontinued
440	ABS-32B-30A	BREAKER	MISUMI	Discontinued
441	ABS-52B-40A	BREAKER	MISUMI	Discontinued
442	ABS-52B-50A	BREAKER	MISUMI	Discontinued
443	ABS-62B-60A	BREAKER	MISUMI	Discontinued
444	ABS-102B-75A	BREAKER	MISUMI	Discontinued
445	ABS-102B-100A	BREAKER	MISUMI	Discontinued
446	ABS-33B-3A	BREAKER	MISUMI	Discontinued
447	ABS-33B-5A	BREAKER	MISUMI	Discontinued
448	ABS-33B-10A	BREAKER	MISUMI	Discontinued
449	ABS-33B-15A	BREAKER	MISUMI	Discontinued
450	ABS-33B-20A	BREAKER	MISUMI	Discontinued

DANH SÁCH SẢN PHẨM SẴP NGỪNG CUNG CẤP
 LIST OF ITEMS TO BE DISCONTINUED (*Be discontinued after clearing stock)

Cập nhật / Update:09-Aug-2019

STT No	Mã hàng Part Number	Tên hàng Product Name	Thương hiệu Brand	Tình trạng / Status Discontinued or Available
451	ABS-33B-30A	BREAKER	MISUMI	Discontinued
452	ABS-53B-40A	BREAKER	MISUMI	Discontinued
453	ABS-53B-50A	BREAKER	MISUMI	Discontinued
454	ABS-63B-60A	BREAKER	MISUMI	Discontinued
455	ABS-103B-75A	BREAKER	MISUMI	Discontinued
456	ABS-103B-100A	BREAKER	MISUMI	Discontinued
457	AX1E100R-LWT	BREAKER	MISUMI	Discontinued
458	AX1E100T-LWT	BREAKER	MISUMI	Discontinued
459	AX1E100R-TBT	BREAKER	MISUMI	Discontinued
460	AX1E100T-TBT	BREAKER	MISUMI	Discontinued
461	AX1H100R-LWT	BREAKER	MISUMI	Discontinued
462	AX1H100T-LWT	BREAKER	MISUMI	Discontinued
463	AX1H100R-TBT	BREAKER	MISUMI	Discontinued
464	AX1H100T-TBT	BREAKER	MISUMI	Discontinued
465	AL1E100R-LWT	BREAKER	MISUMI	Discontinued
466	AL1E100T-LWT	BREAKER	MISUMI	Discontinued
467	AL1E100R-TBT	BREAKER	MISUMI	Discontinued
468	AL1E100T-TBT	BREAKER	MISUMI	Discontinued
469	AL1H100R-LWT	BREAKER	MISUMI	Discontinued
470	AL1H100T-LWT	BREAKER	MISUMI	Discontinued
471	AL1H100R-TBT	BREAKER	MISUMI	Discontinued
472	AL1H100T-TBT	BREAKER	MISUMI	Discontinued
473	AL-22R-B	BREAKER	MISUMI	Discontinued
474	TBS-12B	BREAKER	MISUMI	Discontinued
475	TBL-12B	BREAKER	MISUMI	Discontinued
476	TBS-22B	BREAKER	MISUMI	Discontinued
477	TBL-22B	BREAKER	MISUMI	Discontinued
478	TBL-13B	BREAKER	MISUMI	Discontinued
479	TBS-23B	BREAKER	MISUMI	Discontinued
480	TBL-23B	BREAKER	MISUMI	Discontinued
481	D-35S	BREAKER	MISUMI	Discontinued
482	E-35S	BREAKER	MISUMI	Discontinued
483	EBE-53B-5A	LEAKAGE BREAKER	MISUMI	Discontinued
484	EBE-53B-10A	LEAKAGE BREAKER	MISUMI	Discontinued
485	EBE-53B-15A	LEAKAGE BREAKER	MISUMI	Discontinued
486	EBE-53B-20A	LEAKAGE BREAKER	MISUMI	Discontinued
487	EBE-53B-30A	LEAKAGE BREAKER	MISUMI	Discontinued
488	EBE-53B-40A	LEAKAGE BREAKER	MISUMI	Discontinued
489	EBE-53B-50A	LEAKAGE BREAKER	MISUMI	Discontinued
490	EBE-63B-60A	LEAKAGE BREAKER	MISUMI	Discontinued
491	EBE-103B-75A	LEAKAGE BREAKER	MISUMI	Discontinued
492	EBE-103B-100A	LEAKAGE BREAKER	MISUMI	Discontinued
493	EBS-33B-5A	LEAKAGE BREAKER	MISUMI	Discontinued
494	EBS-33B-10A	LEAKAGE BREAKER	MISUMI	Discontinued
495	EBS-33B-15A	LEAKAGE BREAKER	MISUMI	Discontinued
496	EBS-33B-20A	LEAKAGE BREAKER	MISUMI	Discontinued
497	EBS-33B-30A	LEAKAGE BREAKER	MISUMI	Discontinued
498	EBS-53B-40A	LEAKAGE BREAKER	MISUMI	Discontinued
499	EBS-53B-50A	LEAKAGE BREAKER	MISUMI	Discontinued
500	EBS-63B-60A	LEAKAGE BREAKER	MISUMI	Discontinued
501	EBS-103B-75A	LEAKAGE BREAKER	MISUMI	Discontinued
502	EBS-103B-100A	LEAKAGE BREAKER	MISUMI	Discontinued
503	SMR-63-15S	ELECTROMAGNETIC SWITCH	MISUMI	Discontinued
504	SMR-63-19S	ELECTROMAGNETIC SWITCH	MISUMI	Discontinued
505	SMR-63-21.5S	ELECTROMAGNETIC SWITCH	MISUMI	Discontinued
506	SMR-63-30S	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
507	SMR-63-34S	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
508	SMR-63-42S	ELECTROMAGNETIC SWITCH	MISUMI	Discontinued
509	UW-63	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
510	AU-2-2A	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
511	AU-2-1A1B	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
512	AU-2-2B	ELECTROMAGNETIC SWITCH	MISUMI	Discontinued
513	AU-4-4B	ELECTROMAGNETIC SWITCH	MISUMI	Discontinued
514	AU-4-1A3B	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
515	AU-4-2A2B	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
516	AU-4-3A1B	ELECTROMAGNETIC SWITCH	MISUMI	Discontinued
517	AU-4-4A	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
518	UA-2-2B	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
519	UA-4-1A3B	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
520	UA-4-3A1B	ELECTROMAGNETIC SWITCH	MISUMI	Discontinued
521	AU-2-2A.	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
522	AU-2-1A1B.	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
523	AU-2-2B.	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
524	AU-4-4B.	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
525	AU-4-1A3B.	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable

DANH SÁCH SẢN PHẨM SẴP NGỪNG CUNG CẤP
LIST OF ITEMS TO BE DISCONTINUED (*Be discontinued after clearing stock)

Cập nhật / Update:09-Aug-2019

STT No	Mã hàng Part Number	Tên hàng Product Name	Thương hiệu Brand	Tình trạng / Status Discontinued or Available
526	AU-4-2A2B.	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
527	AU-4-3A1B.	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
528	AU-4-4A.	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
529	AL-22R-W	BREAKER	MISUMI	Avai lable
530	KHK9-AC200V-7.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
531	KHK9-AC200V-19	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
532	KHK9-AC200V-21.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
533	KHK12-AC200V-0.52	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
534	KHK12-AC200V-0.82	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
535	KHK12-AC200V-5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
536	KHK12-AC200V-19	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
537	KHK18-AC200V-0.52	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
538	KHK18-AC200V-0.82	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
539	KHK18-AC200V-1.3	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
540	KHK18-AC200V-5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
541	KHK18-AC200V-6.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
542	KHK18-AC200V-7.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
543	KHK18-AC200V-19	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
544	KHK18-AC200V-27	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
545	KHK22-AC200V-0.52	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
546	KHK22-AC200V-1.3	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
547	KHK22-AC200V-5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
548	KHK22-AC200V-7.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
549	KHK22-AC200V-8.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
550	KHK22-AC200V-11	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
551	KHK32-AC200V-0.52	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
552	KHK32-AC200V-0.82	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
553	KHK32-AC200V-1.3	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
554	KHK32-AC200V-2.1	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
555	KHK32-AC200V-5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
556	KHK32-AC200V-6.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
557	KHK32-AC200V-7.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
558	KHK32-AC200V-8.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
559	KHK32-AC200V-11	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
560	KHK32-AC200V-19	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
561	KHK32-AC200V-21.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
562	KHK65-AC200V-30S	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
563	KHK65-AC200V-34S	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
564	KHK9-AC100V-0.52	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
565	KHK9-AC100V-1.3	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
566	KHK9-AC100V-19	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
567	KHK9-AC100V-21.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
568	KHK9-AC100V-27	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
569	KHK12-AC100V-0.52	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
570	KHK12-AC100V-0.82	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
571	KHK12-AC100V-2.1	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
572	KHK12-AC100V-19	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
573	KHK12-AC100V-21.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
574	KHK12-AC100V-27	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
575	KHK18-AC100V-0.52	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
576	KHK18-AC100V-0.82	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
577	KHK18-AC100V-1.3	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
578	KHK18-AC100V-2.1	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
579	KHK18-AC100V-3.3	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
580	KHK18-AC100V-5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
581	KHK18-AC100V-6.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
582	KHK18-AC100V-8.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
583	KHK18-AC100V-11	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
584	KHK18-AC100V-19	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
585	KHK18-AC100V-21.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
586	KHK22-AC100V-0.52	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
587	KHK22-AC100V-0.82	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
588	KHK22-AC100V-1.3	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
589	KHK22-AC100V-3.3	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
590	KHK22-AC100V-5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
591	KHK22-AC100V-6.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
592	KHK22-AC100V-7.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
593	KHK22-AC100V-8.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
594	KHK22-AC100V-11	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
595	KHK22-AC100V-19	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
596	KHK32-AC100V-0.52	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
597	KHK32-AC100V-0.82	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
598	KHK32-AC100V-1.3	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
599	KHK32-AC100V-3.3	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
600	KHK32-AC100V-5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable

DANH SÁCH SẢN PHẨM SẴP NGỪNG CUNG CẤP
LIST OF ITEMS TO BE DISCONTINUED (*Be discontinued after clearing stock)

Cập nhật / Update:09-Aug-2019

STT No	Mã hàng Part Number	Tên hàng Product Name	Thương hiệu Brand	Tình trạng / Status Discontinued or Available
601	KHK32-AC100V-6.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
602	KHK32-AC100V-7.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
603	KHK32-AC100V-8.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
604	KHK32-AC100V-11	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
605	KHK32-AC100V-19	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
606	KHK32-AC100V-27	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
607	KHK50-AC100V-30S	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
608	KHK50-AC100V-34S	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
609	KHK50-AC100V-55S	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
610	KHK65-AC100V-30S	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
611	KHK65-AC100V-34S	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
612	KHK65-AC100V-55S	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
613	KHK9-DC24V-19	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
614	KHK9-DC24V-27	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
615	KHK12-DC24V-0.52	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
616	KHK12-DC24V-0.82	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
617	KHK12-DC24V-6.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
618	KHK12-DC24V-7.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
619	KHK12-DC24V-19	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
620	KHK12-DC24V-27	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
621	KHK18-DC24V-0.52	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
622	KHK18-DC24V-0.82	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
623	KHK18-DC24V-1.3	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
624	KHK18-DC24V-6.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
625	KHK18-DC24V-11	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
626	KHK18-DC24V-19	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
627	KHK18-DC24V-27	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
628	KHK22-DC24V-0.52	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
629	KHK22-DC24V-0.82	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
630	KHK22-DC24V-1.3	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
631	KHK22-DC24V-2.1	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
632	KHK22-DC24V-3.3	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
633	KHK22-DC24V-5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
634	KHK22-DC24V-6.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
635	KHK22-DC24V-7.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
636	KHK22-DC24V-11	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
637	KHK22-DC24V-15	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
638	KHK6R-AC200V-6.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
639	KHK6R-AC200V-7.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
640	KHK9R-AC200V-1.3	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
641	KHK9R-AC200V-5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
642	KHK9R-AC200V-7.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
643	KHK9R-AC200V-8.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
644	KHK9R-AC200V-15	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
645	KHK9R-AC200V-19	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
646	KHK9R-AC200V-21.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
647	KHK9R-AC200V-27	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
648	KHK12R-AC200V-0.52	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
649	KHK12R-AC200V-0.82	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
650	KHK12R-AC200V-1.3	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
651	KHK12R-AC200V-2.1	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
652	KHK12R-AC200V-3.3	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
653	KHK12R-AC200V-5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
654	KHK12R-AC200V-6.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
655	KHK12R-AC200V-19	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
656	KHK12R-AC200V-27	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
657	KHK18R-AC200V-0.52	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
658	KHK18R-AC200V-0.82	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
659	KHK18R-AC200V-1.3	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
660	KHK18R-AC200V-2.1	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
661	KHK18R-AC200V-3.3	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
662	KHK18R-AC200V-5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
663	KHK18R-AC200V-7.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
664	KHK18R-AC200V-8.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
665	KHK18R-AC200V-11	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
666	KHK18R-AC200V-15	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
667	KHK18R-AC200V-21.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
668	KHK22R-AC200V-0.52	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
669	KHK22R-AC200V-0.82	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
670	KHK22R-AC200V-1.3	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
671	KHK22R-AC200V-2.1	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
672	KHK22R-AC200V-3.3	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
673	KHK22R-AC200V-5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
674	KHK22R-AC200V-6.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
675	KHK22R-AC200V-7.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable

DANH SÁCH SẢN PHẨM SẴP NGỪNG CUNG CẤP
LIST OF ITEMS TO BE DISCONTINUED (*Be discontinued after clearing stock)

Cập nhật / Update:09-Aug-2019

STT No	Mã hàng Part Number	Tên hàng Product Name	Thương hiệu Brand	Tình trạng / Status Discontinued or Available
676	KHK22R-AC200V-8.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
677	KHK22R-AC200V-11	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
678	KHK22R-AC200V-19	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
679	KHK22R-AC200V-21.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
680	KHK22R-AC200V-27	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
681	KHK32R-AC200V-0.52	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
682	KHK32R-AC200V-0.82	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
683	KHK32R-AC200V-1.3	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
684	KHK32R-AC200V-3.3	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
685	KHK32R-AC200V-5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
686	KHK32R-AC200V-7.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
687	KHK32R-AC200V-21.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
688	KHK50R-AC200V-30S	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
689	KHK50R-AC200V-34S	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
690	KHK65R-AC200V-30S	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
691	KHK65R-AC200V-34S	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
692	KHK65R-AC200V-55S	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
693	KHK6R-AC100V-0.52	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
694	KHK6R-AC100V-2.1	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
695	KHK6R-AC100V-5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
696	KHK6R-AC100V-6.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
697	KHK6R-AC100V-7.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
698	KHK6R-AC100V-8.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
699	KHK9R-AC100V-0.52	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
700	KHK9R-AC100V-1.3	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
701	KHK9R-AC100V-2.1	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
702	KHK9R-AC100V-5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
703	KHK9R-AC100V-8.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
704	KHK9R-AC100V-15	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
705	KHK9R-AC100V-19	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
706	KHK9R-AC100V-21.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
707	KHK9R-AC100V-27	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
708	KHK12R-AC100V-0.52	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
709	KHK12R-AC100V-0.82	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
710	KHK12R-AC100V-2.1	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
711	KHK12R-AC100V-3.3	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
712	KHK12R-AC100V-5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
713	KHK12R-AC100V-6.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
714	KHK12R-AC100V-7.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
715	KHK12R-AC100V-11	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
716	KHK12R-AC100V-19	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
717	KHK12R-AC100V-21.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
718	KHK12R-AC100V-27	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
719	KHK18R-AC100V-0.52	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
720	KHK18R-AC100V-0.82	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
721	KHK18R-AC100V-1.3	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
722	KHK18R-AC100V-2.1	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
723	KHK18R-AC100V-5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
724	KHK18R-AC100V-6.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
725	KHK18R-AC100V-7.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
726	KHK18R-AC100V-8.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
727	KHK18R-AC100V-11	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
728	KHK18R-AC100V-15	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
729	KHK18R-AC100V-21.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
730	KHK18R-AC100V-27	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
731	KHK22R-AC100V-0.52	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
732	KHK22R-AC100V-0.82	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
733	KHK22R-AC100V-1.3	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
734	KHK22R-AC100V-3.3	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
735	KHK22R-AC100V-5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
736	KHK22R-AC100V-6.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
737	KHK22R-AC100V-7.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
738	KHK22R-AC100V-8.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
739	KHK22R-AC100V-11	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
740	KHK22R-AC100V-15	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
741	KHK22R-AC100V-19	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
742	KHK22R-AC100V-21.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
743	KHK22R-AC100V-27	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
744	KHK32R-AC100V-0.52	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
745	KHK32R-AC100V-0.82	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
746	KHK32R-AC100V-1.3	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
747	KHK32R-AC100V-2.1	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
748	KHK32R-AC100V-3.3	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
749	KHK32R-AC100V-5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
750	KHK32R-AC100V-7.5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable

DANH SÁCH SẢN PHẨM SẴP NGỪNG CUNG CẤP
 LIST OF ITEMS TO BE DISCONTINUED (*Be discontinued after clearing stock)

Cập nhật / Update:09-Aug-2019

STT No	Mã hàng Part Number	Tên hàng Product Name	Thương hiệu Brand	Tình trạng / Status Discontinued or Available
751	KHK32R-AC100V-11	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
752	KHK32R-AC100V-15	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
753	KHK32R-AC100V-19	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
754	KHK32R-AC100V-21. 5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
755	KHK32R-AC100V-27	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
756	KHK50R-AC100V-30S	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
757	KHK50R-AC100V-34S	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
758	KHK50R-AC100V-55S	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
759	KHK65R-AC100V-30S	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
760	KHK65R-AC100V-34S	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
761	KHK65R-AC100V-55S	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
762	KHK6R-DC24V-5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
763	KHK6R-DC24V-6. 5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
764	KHK9R-DC24V-3. 3	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
765	KHK9R-DC24V-5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
766	KHK9R-DC24V-6. 5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
767	KHK9R-DC24V-8. 5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
768	KHK9R-DC24V-11	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
769	KHK9R-DC24V-15	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
770	KHK9R-DC24V-19	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
771	KHK9R-DC24V-21. 5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
772	KHK9R-DC24V-27	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
773	KHK12R-DC24V-0. 52	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
774	KHK12R-DC24V-0. 82	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
775	KHK12R-DC24V-5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
776	KHK12R-DC24V-6. 5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
777	KHK12R-DC24V-7. 5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
778	KHK12R-DC24V-8. 5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
779	KHK12R-DC24V-11	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
780	KHK12R-DC24V-19	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
781	KHK12R-DC24V-21. 5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
782	KHK12R-DC24V-27	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
783	KHK18R-DC24V-0. 52	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
784	KHK18R-DC24V-0. 82	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
785	KHK18R-DC24V-1. 3	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
786	KHK18R-DC24V-2. 1	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
787	KHK18R-DC24V-3. 3	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
788	KHK18R-DC24V-5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
789	KHK18R-DC24V-6. 5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
790	KHK18R-DC24V-7. 5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
791	KHK18R-DC24V-8. 5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
792	KHK18R-DC24V-11	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
793	KHK18R-DC24V-15	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
794	KHK18R-DC24V-19	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
795	KHK18R-DC24V-21. 5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
796	KHK18R-DC24V-27	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
797	KHK22R-DC24V-0. 52	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
798	KHK22R-DC24V-0. 82	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
799	KHK22R-DC24V-1. 3	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
800	KHK22R-DC24V-2. 1	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
801	KHK22R-DC24V-3. 3	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
802	KHK22R-DC24V-5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
803	KHK22R-DC24V-6. 5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
804	KHK22R-DC24V-7. 5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
805	KHK22R-DC24V-8. 5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
806	KHK22R-DC24V-11	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
807	KHK22R-DC24V-19	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
808	KHK22R-DC24V-21. 5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
809	KHK22R-DC24V-27	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
810	KHK32R-AC200V-6. 5	ELECTROMAGNETIC SWITCH	MISUMI	Avai lable
811	KHK50-AC200V-15S	ELECTROMAGNETIC SWITCH	MISUMI	Discont inued
812	KHK50-AC200V-19S	ELECTROMAGNETIC SWITCH	MISUMI	Discont inued
813	KHK50-AC200V-21. 5S	ELECTROMAGNETIC SWITCH	MISUMI	Discont inued
814	KHK50-AC200V-42S	ELECTROMAGNETIC SWITCH	MISUMI	Discont inued
815	KHK65-AC200V-15S	ELECTROMAGNETIC SWITCH	MISUMI	Discont inued
816	KHK65-AC200V-19S	ELECTROMAGNETIC SWITCH	MISUMI	Discont inued
817	KHK65-AC200V-21. 5S	ELECTROMAGNETIC SWITCH	MISUMI	Discont inued
818	KHK65-AC200V-42S	ELECTROMAGNETIC SWITCH	MISUMI	Discont inued
819	KHK50-AC100V-15S	ELECTROMAGNETIC SWITCH	MISUMI	Discont inued
820	KHK50-AC100V-19S	ELECTROMAGNETIC SWITCH	MISUMI	Discont inued
821	KHK50-AC100V-21. 5S	ELECTROMAGNETIC SWITCH	MISUMI	Discont inued
822	KHK50-AC100V-42S	ELECTROMAGNETIC SWITCH	MISUMI	Discont inued
823	KHK65-AC100V-15S	ELECTROMAGNETIC SWITCH	MISUMI	Discont inued
824	KHK65-AC100V-19S	ELECTROMAGNETIC SWITCH	MISUMI	Discont inued
825	KHK65-AC100V-21. 5S	ELECTROMAGNETIC SWITCH	MISUMI	Discont inued

DANH SÁCH SẢN PHẨM SẴP NGỪNG CUNG CẤP
 LIST OF ITEMS TO BE DISCONTINUED (*Be discontinued after clearing stock)

Cập nhật / Update:09-Aug-2019

STT No	Mã hàng Part Number	Tên hàng Product Name	Thương hiệu Brand	Tình trạng / Status Discontinued or Available
826	KHK65-AC100V-42S	ELECTROMAGNETIC SWITCH	MISUMI	Discontinued
827	KHK50R-AC200V-19S	ELECTROMAGNETIC SWITCH	MISUMI	Discontinued
828	KHK50R-AC200V-21.5S	ELECTROMAGNETIC SWITCH	MISUMI	Discontinued
829	KHK50R-AC200V-42S	ELECTROMAGNETIC SWITCH	MISUMI	Discontinued
830	KHK65R-AC200V-15S	ELECTROMAGNETIC SWITCH	MISUMI	Discontinued
831	KHK65R-AC200V-19S	ELECTROMAGNETIC SWITCH	MISUMI	Discontinued
832	KHK65R-AC200V-21.5S	ELECTROMAGNETIC SWITCH	MISUMI	Discontinued
833	KHK65R-AC200V-42S	ELECTROMAGNETIC SWITCH	MISUMI	Discontinued
834	KHK50R-AC100V-15S	ELECTROMAGNETIC SWITCH	MISUMI	Discontinued
835	KHK50R-AC100V-19S	ELECTROMAGNETIC SWITCH	MISUMI	Discontinued
836	KHK50R-AC100V-21.5S	ELECTROMAGNETIC SWITCH	MISUMI	Discontinued
837	KHK50R-AC100V-42S	ELECTROMAGNETIC SWITCH	MISUMI	Discontinued
838	KHK65R-AC100V-15S	ELECTROMAGNETIC SWITCH	MISUMI	Discontinued
839	KHK65R-AC100V-19S	ELECTROMAGNETIC SWITCH	MISUMI	Discontinued
840	KHK65R-AC100V-21.5S	ELECTROMAGNETIC SWITCH	MISUMI	Discontinued
841	KHK65R-AC100V-42S	ELECTROMAGNETIC SWITCH	MISUMI	Discontinued
842	KHK50R-AC200V-15S	ELECTROMAGNETIC SWITCH	MISUMI	Discontinued
843	UA-4-4B	ELECTROMAGNETIC SWITCH	MISUMI	Discontinued
844	ABE-53B-15A	BREAKER	MISUMI	Discontinued
845	CPRM-2P-5A	CIRCUIT PROTECTOR	MISUMI	Avai lable
846	CPRM-2P-10A	CIRCUIT PROTECTOR	MISUMI	Avai lable
847	CPRM-2P-3A	CIRCUIT PROTECTOR	MISUMI	Avai lable
848	CPRM-2P-2A	CIRCUIT PROTECTOR	MISUMI	Discontinued
849	CPRM-2P-1A	CIRCUIT PROTECTOR	MISUMI	Avai lable
850	CPRM-2P-15A	CIRCUIT PROTECTOR	MISUMI	Avai lable
851	CPRM-1P-2A	CIRCUIT PROTECTOR	MISUMI	Avai lable
852	CPRM-1P-5A	CIRCUIT PROTECTOR	MISUMI	Avai lable
853	CPRM-3P-5A	CIRCUIT PROTECTOR	MISUMI	Avai lable
854	CPRM-1P-1A	CIRCUIT PROTECTOR	MISUMI	Avai lable
855	CPRM-2P-20A	CIRCUIT PROTECTOR	MISUMI	Avai lable
856	CPRM-1P-3A	CIRCUIT PROTECTOR	MISUMI	Avai lable
857	CPRM-3P-1A	CIRCUIT PROTECTOR	MISUMI	Avai lable
858	CPRM-3P-3A	CIRCUIT PROTECTOR	MISUMI	Avai lable
859	CPRM-3P-10A	CIRCUIT PROTECTOR	MISUMI	Avai lable
860	CPRM-1P-10A	CIRCUIT PROTECTOR	MISUMI	Avai lable
861	CPRM-2P-30A	CIRCUIT PROTECTOR	MISUMI	Avai lable
862	CPRM-3P-2A	CIRCUIT PROTECTOR	MISUMI	Avai lable
863	CPRM-3P-15A	CIRCUIT PROTECTOR	MISUMI	Avai lable
864	CPRM-3P-20A	CIRCUIT PROTECTOR	MISUMI	Avai lable
865	CPRM-1P-15A	CIRCUIT PROTECTOR	MISUMI	Avai lable
866	CPRM-3P-30A	CIRCUIT PROTECTOR	MISUMI	Avai lable
867	CPAX	CIRCUIT PROTECTOR	MISUMI	Avai lable
868	CPRM-1P-30A	CIRCUIT PROTECTOR	MISUMI	Avai lable
869	CPRM-1P-20A	CIRCUIT PROTECTOR	MISUMI	Avai lable
870	9MD1B-TM-DC125-4P4T	PV BREAKER	MISUMI	Avai lable
871	DPAM-C2-VW10S-8	DISPLAY MOUNT	MISUMI	Avai lable
872	DPAM-C2-FW10S-6	DISPLAY MOUNT	MISUMI	Avai lable
873	DPAM-C2-FW10S	DISPLAY MOUNT	MISUMI	Avai lable
874	DPAM-C2-HW10S-6	DISPLAY MOUNT	MISUMI	Avai lable
875	DPAM-C2-VW10S	DISPLAY MOUNT	MISUMI	Avai lable
876	DPAM-C2-HW10S	DISPLAY MOUNT	MISUMI	Avai lable
877	EMVM-DE-USB	MICROSCOPE	MISUMI	Avai lable
878	DPAM-C2-VW10S-6	DISPLAY MOUNT	MISUMI	Avai lable
879	DPAM-C2-FW11S	DISPLAY MOUNT	MISUMI	Avai lable
880	PCFM-USB2G	FLASH EXTENSION	MISUMI	Avai lable
881	DPAM-C6-FW731S	DISPLAY	MISUMI	Avai lable
882	DPAM-C2-FW10S-8	DISPLAY MOUNT	MISUMI	Avai lable
883	DPAM-C2-HW10S-8	DISPLAY MOUNT	MISUMI	Avai lable
884	PCFM-USB4G	FLASH EXTENSION	MISUMI	Avai lable
885	DPAM-C2-HW11S-6	DISPLAY MOUNT	MISUMI	Avai lable
886	DPAM-C2-FW12S	DISPLAY MOUNT	MISUMI	Avai lable
887	PCMS-AIR-US	MOUSE	MISUMI	Avai lable
888	PCMS-AIR-USW	MOUSE	MISUMI	Avai lable
889	DPAM-C2-FW11S-6	DISPLAY MOUNT	MISUMI	Avai lable
890	DPAM-C2-HW11S	DISPLAY MOUNT	MISUMI	Avai lable
891	PCST-DT9205T	TESTER	MISUMI	Avai lable
892	PCMS-LED-USB	MOUSE	MISUMI	Discontinued
893	DPAM-C6-CM108	DISPLAY	MISUMI	Discontinued
894	PNUSH-USB4	USB HUB	MISUMI	Discontinued
895	DPAM-C2-FW11S-8	DISPLAY MOUNT	MISUMI	Avai lable
896	PCMS-MINI-BLACK	MOUSE	MISUMI	Discontinued
897	DPAM-C2-HW11S-8	DISPLAY MOUNT	MISUMI	Avai lable
898	EMVM-DE-SD	MICROSCOPE	MISUMI	Avai lable
899	PCST-MF47B	TESTER	MISUMI	Avai lable
900	EMVM-MAG	MICROSCOPE	MISUMI	Avai lable

DANH SÁCH SẢN PHẨM SẴP NGỪNG CUNG CẤP
 LIST OF ITEMS TO BE DISCONTINUED (*Be discontinued after clearing stock)

Cập nhật / Update:09-Aug-2019

STT No	Mã hàng Part Number	Tên hàng Product Name	Thương hiệu Brand	Tình trạng / Status Discontinued or Available
901	PCST-TY3066TD	TESTER	MISUMI	Available
902	PCST-TY3066TA	TESTER	MISUMI	Available
903	PCFM-USB32G	FLASH EXTENSION	MISUMI	Available
904	PCFM-USB64G	FLASH EXTENSION	MISUMI	Available
905	DPAM-LDA06-112	DISPLAY MOUNT	MISUMI	Available
906	DPAM-LDA06-221	DISPLAY MOUNT	MISUMI	Available
907	PCMTL-BL30	MACHINE VISION	MISUMI	Available
908	PNUIC-TBCARD	TABLET PC	MISUMI	Available
909	PCTP-OTG-U	TABLET PC	MISUMI	Available
910	PCMTL-BR30	MACHINE VISION	MISUMI	Available
911	PCMS-TBAG	MOUSE	MISUMI	Discontinued
912	PCMS-M602	MOUSE	MISUMI	Discontinued
913	KBD-32K-PC	POWER PARTS	MISUMI	Discontinued
914	IESH-MB305P-AC	AC ADAPTER FOR ETHERNET HUB	MISUMI	Discontinued
915	PCMTL-DE-1701.	DISPLAY	MISUMI	Discontinued
916	PCMTL-DE-1701	DISPLAY	MISUMI	Discontinued
917	PNUIC-READER	USB CONVERTER	MISUMI	Discontinued
918	PCTP-R7	TABLET PC	MISUMI	Discontinued
919	PCTP-R7.	TABLET PC	MISUMI	Discontinued
920	PCTP-AC	TABLET PC	MISUMI	Discontinued
921	PCTP-R10	TABLET PC	MISUMI	Discontinued
922	PCTP-R10.	TABLET PC	MISUMI	Discontinued
923	PCTP-FS	TABLET PC	MISUMI	Discontinued
924	PCTP-FT	TABLET PC	MISUMI	Discontinued
925	PCTP-TFUSB-W	TABLET PC	MISUMI	Discontinued
926	DPAM-C2-VW11S-6	DISPLAY MOUNT	MISUMI	Discontinued
927	DPAM-C2-VW11S-8	DISPLAY MOUNT	MISUMI	Discontinued
928	PCTP-TF4G	TABLET PC	MISUMI	Discontinued
929	PNUIC-TBCARD2	TABLET PC	MISUMI	Available
930	PCMS-MINI-BLACK.	MOUSE	MISUMI	Discontinued
931	DPAM-LDA06-222	DISPLAY MOUNT	MISUMI	Available
932	PCFP-MV-DC24.	MACHINE VISION	MISUMI	Discontinued
933	KVMIO-AC-C.	KVM SWITCH	MISUMI	Discontinued
934	PCTP-TFUSB	TABLET PC	MISUMI	Discontinued